

Jerome® J605 Quick Guide

Remember to read the J605 user's manual for complete details on instrument operation, maintenance, and troubleshooting, to optimize the results and extend the life of the instrument. An up-to-date electronic copy of the manual can be found at: <http://www.azic.com/downloads.aspx>.

The Jerome J605 is easy to operate and ready for immediate use when you receive it. Follow these brief steps:

- 1) **UNPACK:** Remove the instrument from the packing material. Check for any damage and confirm receipt of all parts on your packing list.

Retain all packaging materials for future shipping needs.

- 2) **POWER UP:** Press the I/O button. The display should read 0.000 ppm.

Note: It may be necessary to press [ESC] to clear any calibration reminders.

The battery icon will display the current battery level. If the battery icon is empty and flashing, it is necessary to charge the battery by connecting the J605 to AC power. See the manual for details.

- 3) **BEFORE SAMPLING:**

Sensor Regen: Perform a sensor regeneration by following these steps:

- Plug the line cord/AC adapter power supply or the external battery pack into the back of instrument
- Press the RIGHT arrow button (▶) to enter the main menu.
- Press the DOWN arrow button (▼) to move the cursor to **Regen**.
- Press the RIGHT arrow button (▶) to select **Regen**.
- Press **[ENTER/START]** to select **Regen Now** on the REGEN menu.
- The instrument will begin the 45-minute regeneration cycle.

Do not interrupt this cycle. If any error message appears on the display, see the Troubleshooting section of the user's manual.

- 4) **TAKING A SAMPLE:** The instrument is designed for ambient air monitoring.

Note: For EPA clean-up levels less than 10 ppb, it is necessary to run a warm-up routine with the Zero Air Filter before sampling. See the manual for details.

- For maximum testing accuracies and performance, allow the instrument to warm-up for 5 minutes before sampling.
- Press the SAMPLE button located at the end of the handle to start the sampling cycle.
 - **DO NOT allow the probe or the instrument's intake to come in contact with liquids.**
 - **Note that the instrument is not explosion proof.**
 - **DO NOT obstruct the intake or exhaust ports.**

- 5) **STORAGE:** After the day's use, perform another sensor regeneration.

Call AZI Customer Service, or your Technical Sales Representative, at 800-235-3360 or 602-470-1414 or send an email to support@azic.com if you have any questions.



ARIZONA INSTRUMENT LLC

3375 N. Delaware Street, Chandler, AZ 85225 • (602) 470-1414 • (800) 528-7411 • www.azic.com

Exclusive Manufacturer of Computrac® Moisture Analyzers and Jerome® Toxic Gas Analyzers

700-0118-A